

# Cannular Quick Start Guide

## Set Up:

1. Unbox your Cannular making sure to check for loose parts.
2. Remove the parts bag and set aside.
3. Cut the zip tie and unwrap the can holder.
4. The turn table should be assembled, but it may have come apart in shipping. The bearing is three parts – 2 races and the ball cage. To reassemble:
  - a. Place one race in the turn table support with the concave side facing up.
  - b. Install the ball cage on the race.
  - c. Place the final race on top of the ball cage with the concave side facing down.
  - d. Insert the plastic turn table.
5. Install the top lever on the right side of the case.
6. Install the bottom lever on the can lift assembly.
7. Connect your power supply to the power socket on the back.
8. Adjust the can lift by placing a can and lid on the lift assembly.
  - a. Pull the lift lever towards you.
  - b. The lever should get slightly stiff at the end and ease into a locked position.
  - c. If the lever is too loose, screw the can adjustment up.
  - d. If the lever is too tight, lower the can adjustment.
  - e. With practice you will find the perfect adjustment.



## Seaming Your First Can:

1. Fill the can with liquid. Water might be a good choice for practicing.
2. Put the filled can on the turn table.
3. Place a lid on the can.
4. Raise the can till you feel the can lock in place.
5. Turn on the seamer.
6. Push on the top lever to roll the seam around (1st Op).
7. Pull on the lever to tighten the seam (2nd Op).
8. Turn off the seamer.
9. Remove the can and check for leaks.